

# **INSTALLATION INSTRUCTIONS: SKELETONIZED STOCK YHM-9569**

**ONLY a licensed gunsmith experienced with your model of firearm should install this product. Failure to install this product correctly voids any warranties of the product and removes any liabilities against the manufacturer. Be certain the firearm is unloaded and the muzzle is pointed in a safe direction before starting this removal and installation process.**

- (1) With the muzzle pointing down, remove the top screw in your existing butt stock using a proper fitting screw driver.
- (2) Keeping the muzzle pointing down, slide off your old stock.

NOTE: on the right side of the buffer tube at your receiver there is a spring protruding. Be certain it stays in place.

- (3) Remove the spacer butt cap from the end of your buffer tube if it did not slide off with the old stock.
- (4) Slide your new stock over the buffer tube being certain to compress the spring mentioned above without bending it over.
- (5) Install the new stock screw provided and tighten it firmly with a proper fitting screw driver.